




# Spares List

## Model: 40A Series



<b><u>DESCRIPTION</u></b>	<b><u>PART NO.</u></b>
Bearing Plate	45140
Bearing Plate (Optional-316L SS)	98061
Plate Seal	45352
Permeate Port	50898
Permeate Port Seal	45335
PWT/Adapter Seal	45296
Port Retainer	45242
Retaining Ring	45260
Head Assembly	50234
<b><u>Vessel Support for 40A</u></b>	
Saddle	45058
Strap Assembly	47459